

AXIS Companion – Remote System Management

User Manual

AXIS Companion — Remote System Management

Introduction

Remote access to a surveillance system can save a lot of time and money when maintaining and troubleshooting a system.

With the Remote System Management tool for AXIS Companion you get an overview of the installations and can undertake simple maintenance steps right away, such as:

- Restarting devices
- Upgrading devices
- Manage user permissions

Get started

Note

Only users with administrator rights have access to the sites.

1. Go to <https://connect.axis.com>
2. Log in to your MyAxis account.

A list of your sites is shown.



Sites


Has error

 Demo site	⋮
 Main building	⋮
 My site	⋮

- To find a site, type in the search field.
- To only display sites that contain errors, click **Has error**.
- To sign out, click the initials menu and then **Sign out**.
- To see who is currently logged in, click the initials menu.

AXIS Companion — Remote System Management

Manage sites



- To invite a user to a site:

1. Click  > **Users**.
2. Click **Add user**.
3. Enter the email of the user and select a permission level:
 - **Viewer**: Access to **Live view**.
 - **Operator**: Access to **Live view** and **Recordings**.
 - **Administrator**: Access to **Live view**, **Recordings** and **Configuration**.
4. Click **Invite**.

- To remove a user from a site:

1. Click  > **Users**.
2. Click  > **Remove from site**.

- To rename a site, click  > **Rename**.

- To remove a site, click  > **Remove**.


- Click a site to open it.

A list of the devices that belong to the site is shown.

AXIS Companion — Remote System Management

Manage devices

When you open a site, you see a list of all the devices that belong to that site.



- Click a device to see its properties.
- Upgrade the firmware of a single device:
 1. Click the device to see its properties.
 2. Click **Upgrade**.
- Upgrade the firmware of all devices at once:
 1. Click **Upgrade all** (the option is only visible when there are several available firmware updates).

Note

A firmware upgrade can take several minutes.

- To rename a device, click  > **Rename**.
- To restart a device, click  > **Restart**.
- To remove a device, click  > **Delete**.

